




# AVX

Model: EKP AVX  
 Model: SK AVX  
 Model: SKM AVX  
 Model: SKM-S AVX

Quick Guide  
 Kurzanleitung  
 Guide rapide  
 Guida rapida  
 Guía de inicio rápido  
 Guia rápido  
 Beknopte handleiding  
 Krótka instrukcja obsługi  
 Snabbguide

Kort vejledning  
 Pikaohje  
 Γρήγορος οδηγός  
 Kısa Kılavuz  
 Краткая инструкция  
 快速指南  
 快速使用指南  
 クイックガイド  
 퀵 가이드

## SENNHEISER



### Sennheiser Documentation App





or online at  
[www.sennheiser.com/download](http://www.sennheiser.com/download)  
 AVX\_

Sennheiser electronic GmbH & Co. KG


Am Labor 1, 30900 Wedemark, Germany  
[www.sennheiser.com](http://www.sennheiser.com)

Printed in Germany, Publ. 07/21, 583901/A03

### Video digital wireless




### In the box



EKP AVX



BA 20



EKP AVX Adapter



CI 400

### All Sets

#### Lavalier Set (Pro)




SK AVX




BA 30



ME 2 or  
MKE 2 (Pro)



#### Handheld Set



SKM AVX



BA 10



#### Combo Set



SK AVX



BA 30



SKM AVX




BA 10



ME 2


NT 5-10U




USB

### Battery


SKM AVX  
BA 10



SK AVX  
BA 30




EKP AVX  
BA 20



### Charging



BA 10/BA 30

BA 20





BA 10/BA 30	BA 20	Charge Level	Indicator
1:00 h	0:15 h	30%	🔴
2:00 h	0:30 h	60%	🔴
3:00 h	0:40 h	75%	🔴
4:30 h	1:15 h	100%	🟢

### Battery check



Check	Indicator
> 3 h	🟢🟢🟢🟢
> 2 h	🟡🟢🟢🟢
> 1 h	🟡🟡🟢🟢
> 15 min	🟡🟡🟡🟢
< 15 min	🔴🟡🟡🟡

### On/Off





### Changing pairing


1



2



3



4



**Setup**

**Video camera** | XLR-3

**DSLR | 1**

**2**

**3**

**4**

**5**

**6** | CI 400

**Belt**

**i** STOP! max. 320° STOP!

**Audio level**

**1**

**2**

**3**

**Auto ON/OFF**

INPUT LEVEL

- ✗ Auto
- ✓ Manual


LEVEL

AF Out

Line | Mic | Mic P48

OFF | ON

# MKE 2 + ME 2



**MKE 2** | **ME 2**

**MKE 2** | **ME 2**

**MKE 2** | **ME 2**

**MKE 2** | **ME 2**

- 20 dB ✓

- 30 dB ✓

**Clip**

**ME 2 | 1**

**2**

**MKE 2 | 1**

**2A**

**2B**

**MKE 2 | 1**

**2**

**3**

**4**