

# DVI-D to DVI-I Scaler Box

CP-254

Operation Manual



## I. Introduction

### Cypress's high performance scaler/processor family

| Spec.      | Signal Type    | Connector     | Format                             |
|------------|----------------|---------------|------------------------------------|
| Model      | Input Output   | Input Output  | Input Output                       |
| VGA2D/2WAV | Analog         | HD-15F        | PC-RGB+HDTV-RGB/YPbPr(Auto/Manual) |
| VGA2D/VII  | Digital/Analog | HD-15F        | PC-RGB+HDTV-RGB/YPbPr(Auto/Manual) |
| DVI2vGA    | Digital        | DVI-D         | PC-RGB+HDTV-RGB/YPbPr(Auto/Manual) |
| DVI2DVI    | Digital/Analog | DVI-D         | PC-RGB+HDTV-RGB/YPbPr(Auto/Manual) |
| VID2VGATV  | Analog         | RCA/4Din/7Din | CVBS/S-Video/TUV/RGsB(Manual)      |
| VIDD2VIDV  | Analog         | RCA/4Din/7Din | CVBS/S-Video/TUV/RGsB(Manual)      |

#### Note:

4 Din:4-pin mini Din

7 Din: 7-pin mini Din

RGsB: RGB Sync on Green

Table 1

## **Features:**

1. CP-254 is a high performance DVI scaler that accepts Digital DVI-D input and converters to DVI-I (digital + analog RGB) output.
2. The input to the CP-254 is digital PC or HDTV signal in the fromat of either RGBHV or YPbPr/YCbCr data bitstream via 24-pin DVI connector.
3. The output of the CP-254 is digital + analog PC or HDTV signal in the format of digital RGBHV bitstream plus analog RGBHV,known as DVI-I (Integrated digital and analog).
4. The input resolution is automatically detected while the output resolution and refresh rate can be selected through OSD menu and front panel push buttons.
5. 48 MB frame memory for frame rate conversion.
6. Output picture adjustment on brightness, Contast, Color, RGB level, and H-V position.
7. DVI output enables an all digital rendering of video without the losses associated with an analog interface and is ideal for use with digital display such as LCD, Plasma and DLP projectors.

## **2. What's included:**

The following items are included in the standard package.

1. DVI cable x 1.
2. AC power adaptor 5V/2A.

## **Installation**

### **Input connection:**

The CP-254 can accept both PC and HDTV input in the format of digital DVI. Use the DVI-to DVI cable to connect the DVI output of a PC or HDTV device to the DVI input connector of the CP-254.

### **Output connection:**

The CP-254 can output a variety of PC resolution and HDTV progressive resolution, in both digital and analog format.

To use CP-254 digital output select " DVI-D " in the Output Setup of the menu, and use DVI cable to connect the DVI output of the CP-254 to the DVI input of a display monitor, or HDTV device.


To use analog output of the CP-254 , select " DVI-A" in the Output Setup of the menu, and use the DVI to VGA adaptor to transfer analog output into VGA configuration, which can subsequently connect to the VGA input of a display monitor through a VGA cable when one of the PC resolution is selected as output; or connect to the YPbPr input of a HDTV device through a VGA to YPbPr/3RCA adaptor cable when one of the HDTV resolution is selected as output.

### 3. Installation


#### 3.3 Connections :

- A. For digital RGB (DVI) output, (Select DVI-D in the Output Setup of the menu).

##### (a) PC in to Digital PC or HDTV out



##### (b) HDTV in to Digital PC or HDTV out




### 3. Installation


#### 3.3 Connections :

- B. For analog RGB(VGA) output, (Select DVI-A in the Output Setup of the menu).

#### (a) PC in to PC or HDTV out




#### (b) HDTV in to PC or HDTV out



# Configuration & Operation

## Front and Rear Panels



## Menu and Adjustments

Pressing the Menu button will bring up the OSD menu controls on the screen as follows:

- \* Input set up
- \* Picture Adjust
- \* HV Adjust
- \* OSD Adjust
- \* System Information
- \* Auto Adjust
- \* Exit

Use +,- to move the arrow cursor to your desired selection, then press MENU to confirm your selection and enter into sub menu.

Use +,- to choose the parameter you want to adjust and then press the Menu (Enter) to highlight your selection. Once a parameter is highlighted, use +,- to increase or decrease the setting value.

Press Menu (Enter) again to leave the setting. Move the arrow to exit then press Menu/Enter to Exit.

**Input set up** - When it is selected, a sub menu as below will appear.

YPbPr  RGB

The CP-254 will automatically detect and show the input signal format as YPbPr or RGB.

You can also manually select the YPbPr or RGB to match the format of your input. Selecting a format that doesn't coincide with your input will result in an abnormal picture.

## 4.Configuration & Operation

### 4.2 Menu and Adjustments

**Output set up**-When it is selected, a sub-menu as below appears.

|       |         |
|-------|---------|
| DVI-A | DVI-D   |
| Mode  | XXXX-XX |

Select DVI-A when you would like to use analog output of CP-254.

Select DVI-D when you would like to use digital output of CP-254.

When DVI-A is selected, it gives you choice for the output mode as follow:

**Output modes under DVI-A.**

| PC (RGBHV) |           |                | HDTV (YPbPr, RGBHV) |           |       |
|------------|-----------|----------------|---------------------|-----------|-------|
| VGA        | 640X480   | 60/72/75/85 Hz | 1080i -RGB          | 1920X1080 | 60 Hz |
| VESA85     | 640X400   | 85 Hz          | 720p -RGB           | 1280X720  | 60 Hz |
| VGA70      | 720X400   | 70 Hz          | 576p -RGB           | 720X576   | 50 Hz |
| SVGA       | 800X600   | 60/72/75/85 Hz | 480p -RGB           | 720X480   | 60 Hz |
| XGA        | 1024X768  | 60/70/75/85 Hz | 1080i -YPbPr        | 1920X1080 | 60 Hz |
| Mac        | 1152X864  | 70/75 Hz       | 720p -YPbPr         | 1280X720  | 60 Hz |
| WXGA       | 1280X768  | 60 Hz          | 576p -YPbPr         | 720X576   | 50 Hz |
| 1280A      | 1280X960  | 60 Hz          | 480p -YPbPr         | 720X480   | 60 Hz |
| SXGA       | 1280X1024 | 60/75 Hz       |                     |           |       |

When DVI-D is selected, it gives you choices for the output mode as follows:

**Output modes under DVI-D.**

| PC (RGBHV) |           |                | HDTV (RGBHV) |           |       |
|------------|-----------|----------------|--------------|-----------|-------|
| VGA        | 640X480   | 60/72/75/85 Hz | 1080i -RGB   | 1920X1080 | 60 Hz |
| VESA85     | 640X400   | 85 Hz          | 720p -RGB    | 1280X720  | 60 Hz |
| VGA70      | 720X400   | 70 Hz          | 576p -RGB    | 720X576   | 50 Hz |
| SVGA       | 800X600   | 60/72/75/85 Hz | 480p -RGB    | 720X480   | 60 Hz |
| XGA        | 1024X768  | 60/70/75/85 Hz |              |           |       |
| Mac        | 1152X864  | 70/75 Hz       |              |           |       |
| WXGA       | 1280X768  | 60 Hz          |              |           |       |
| 1280A      | 1280X960  | 60 Hz          |              |           |       |
| SXGA       | 1280X1024 | 60/75 Hz       |              |           |       |

**Use +,- to choose your desired PC or HDTV resolution.**

**Picture Adjust**-When it is selected the following adjust parameters will appear:

|        |  |     |
|--------|--|-----|
| Cont.  |  | 070 |
| Bright |  | 130 |
| Color  |  | 070 |
| Reset  |  |     |
| Exit   |  |     |

# Configuration & Operation

## Menu and Adjustments

The adjustment range and factory preset value as follows:

|          | Range | Default |
|----------|-------|---------|
| Contrast | 0~255 | 047     |
| Bright   | 0~255 | 102     |
| Color    | 0~255 | 064     |

Use +,- and MENU/Enter to adjust the value of your selected parameter.  
Select reset to reset all adjustment back to the factory preset value.

**HV adjust-** When it is selected the following sub-menu appears.

|            |   |     |
|------------|---|-----|
| H-position |  | 184 |
| V-position |  | 32  |

Use +,- to adjust the best horizontal and vertical position of the picture.

**OSD adjust-** When it is selected, you can adjust the Horizontal and Vertical position of the OSD menu.

**System information-** When it is selected, it shows the input/output resolution and their vertical refresh rate on the screen.

**Auto adjust-** When it is selected the CP-254 will automatically adjust all the parameter to the factory preset value.

**Exit-** Select to exit from the current page.

### Notes:

- \* The default output resolution of the CP-254 is XGA@60Hz.
- \* The unit has non-volatile memory and memorizes all your settings before power off and recalls those settings on next power on.
- \* At any time, pressing + and - buttons simultaneously will reset the output resolution to XGA@60Hz, and other settings back to factory default values.

## 5. Specifications

### Input resolutions:

| Digital       | PC (RGBHV) |                | HDTV(YPbPr,RGBHV) |           |       |
|---------------|------------|----------------|-------------------|-----------|-------|
| <b>VGA</b>    | 640X480    | 60/72/75/85 Hz | <b>1080i</b>      | 1920X1080 | 60 Hz |
| <b>VESA85</b> | 640X400    | 85 Hz          | <b>720p</b>       | 1280X720  | 60 Hz |
| <b>VGA70</b>  | 720X400    | 70 Hz          | <b>576p</b>       | 720X576   | 50 Hz |
| <b>SVGA</b>   | 800X600    | 60/72/75/85 Hz | <b>480p</b>       | 720X480   | 60 Hz |
| <b>XGA</b>    | 1024X768   | 60/70/75/85 Hz | <b>576i</b>       | 720X576   | 50 Hz |
| <b>Mac</b>    | 1152X864   | 70/75 Hz       | <b>480i</b>       | 720X480   | 60 Hz |
| <b>WXGA</b>   | 1280X768   | 60 Hz          |                   |           |       |
| <b>1280A</b>  | 1280X960   | 60 Hz          |                   |           |       |
| <b>SXGA</b>   | 1280X1024  | 70/75 Hz       |                   |           |       |

### Output resolutions:

| Digital/Analog | PC (RGBHV) |                | HDTV (RGBHV, YPbPr) <sup>*</sup> |           |       |
|----------------|------------|----------------|----------------------------------|-----------|-------|
| <b>VGA</b>     | 640X480    | 60/72/75/85 Hz | <b>1080i</b>                     | 1920X1080 | 60 Hz |
| <b>VESA85</b>  | 640X400    | 85 Hz          | <b>720p</b>                      | 1280X720  | 60 Hz |
| <b>VGA70</b>   | 720X400    | 70 Hz          | <b>576p</b>                      | 720X576   | 50 Hz |
| <b>SVGA</b>    | 800X600    | 60/72/75/85 Hz | <b>480p</b>                      | 720X480   | 60 Hz |
| <b>XGA</b>     | 1024X768   | 60/72/75/85 Hz |                                  |           |       |
| <b>Mac</b>     | 1152X864   | 70/75 Hz       |                                  |           |       |
| <b>WXGA</b>    | 1280X768   | 60 Hz          |                                  |           |       |
| <b>1280A</b>   | 1280X960   | 60 Hz          |                                  |           |       |
| <b>SXGA</b>    | 1280X1024  | 60/75 Hz       |                                  |           |       |

\* HDTV YPbPr format only available on Analog out.

**Input format:** Digital RGBHV, YPbPr or YCbCr

**Input signal:** Digital RGB data bitstream

**Input connector:** 24-pin DVI-D connector

**Output format:** Analog RGBHV+Analog RGBHV or  
YPbPr (through DVI to HD-15 adaptor)

**Output signal:** Digital data bitstream

**Output connector:** 24-pin DVI-D connector

**Power:** 5V 2A center-positive



