# Installation

## **Floor-standing Signage Installation**

The images below are for reference only, please refer to the actual device for details.

### Prerequisites

Purchase the casters as needed.


#### Procedure

- <u>Step 1</u>
- 0 1 Open the package, and then take out the signage, base, base fasteners, casters, screws and Allen wrench.

Only 75-inch signage includes the base fastener.


<u>Step 2</u> Use the Allen wrench to remove the screws at the bottom of the Signage.

Figure 1-1 Remove the screws




<u>Step 3</u> Insert the Signage into the base.

Figure 1-2 Insert into the base



<u>Step 4</u> Use the allen wrench to tighten the screws.

#### Figure 1-3 Tighten the screws



Step 5 Attach the base fastener to both sides of the Signage, and then use screws to secure the base fastener to the Signage.

This step is available for 75-inch signage.




Figure 1-4 Attach the base fastener

#### Step 6 (Optional) Use the screws to install the casters onto the base of the Signage.

Figure 1-5 Install the casters

