





Feature:

- * Support network extension function.

- * Support network extension random.

 * Support power supply function.

 * Connect the controller and the unit. The last unit is connected back to the controller to realize the loop redundancy function.

 * When the loop detection is disconnected, the ACTIVE indicator light is on.

 * When the loop detection is closed, the ACTIVE indicator light is off.

 * Our part and absolute function. When internal self-checking fault occurs, the ERROR indicator light stays on, and it goes out. * Support self-checking function. When internal self-checking fault occurs, the ERROR indicator light stays on, and it goes out when the fault is solved or there is no fault.

 * Connected to a power adapter for power supply.

Specification:

Model	TS-0321
Power consumption	1.8W
Supply voltage/current	36V/2A
Connection method	Special cable (6-pin aviation cable)
Color	Silver
Weight	660g
Dimension	180*111*40mm
Working temperature	0~60°C
Relative humidity	20%~80%, no condensation