HDS-720 Network AV Controller

User Manual



BXB ELECTRONICS CO., LTD.

Index

1
2
4
5
6
8
9
0





Safety Instructions

- 1. Please read the instruction manual carefully before installing and using the apparatus.
- 2. Please save the instruction manual well for reference.
- 3. Please follow the instructions and aware of warning indications.
- 4. Except your dealer, please do not use any spare parts recommended by others.
- 5. Please use the fixing accessories provided by BXB. If the system is broken due to the improper fixing, BXB would not bear the responsibility for compensation.
- 6. Please make sure the power cord has been fixed properly.
- 7. Do not use any three-hole plugs or extension cords as this would result in fire or short circuit.
- 8. Do not stuff anything into the apparatus or splash any liquid on it.
- 9. Please contact maintenance technicians if the conditions below occur:
 - A. Power cord or plug is damaged.
 - B. Liquid has been spilled into the apparatus.
 - C. The system cannot operate normally even everything has followed the instructions.
 - D. The apparatus fall down or the cover is damaged.

E. Other problems that need to be repaired.

- 10. To reduce the risk of damage caused by lightning strike, it is essential that all cables must be bonded well to the same grounding point.
- 11. Install the apparatus and its other equipment carefully. Impacting and fierce shaking should be avoided.
- 12. Do not disassemble or remodel the the apparatus:
 A. High voltage and sensitive electrical circuit are inside of the apparatus. Do not disassemble it to prevent electric shock.
 B. The specification of any replaced spare part should be validated by manufacturer, or it may cause fire and short circuit.
- Do not use the apparatus in the environment with improper temperature, moisture, and power level: the adequate range is 0°C ~ 40°C (32°F ~ 104°F) and 90% below of moisture.
- 1. Do not expose the apparatus to rain and moisture. Put it in a dry location to avoid any damage of the inside components.
- 2. Do not clean the apparatus and its accessories with chemical detergent. Use a cloth dampened a little bit water instead.
- 3. Do not switch on/off the power of apparatus rapidly no matter it's operating or off. It can maintain the regular operation of the sensitive electronic circuit.

Caution: Please aware of the voltage accordance with that in your country. Warning: Only qualified maintenance technicians can disassemble the cover of apparatus.





- ① Power supply: connect with AC100-230V to DC-5V adapter.
- ^② Power status indicator: turn on when the power status is normal; turn off when there's the abnormal condition of power supply.
- ③ Trigger contact IN: the preserved contact.
- ④ RS-232 port: for connecting with BXB's conference MCU
- © RS-485 port: for connecting with HDK-700 Compact Camera Controller (TX+ & TX-) to control PTZ cameras.
- © Audio port: perserved for extended functions.
- ⑦ USB port: perserved for extended functions.
- Internet port: for connecting with BXB's conference equipment or PC to operate graphical software and set the system configuration
- IDMI OUT: connect with monitors for displaying the image-tracking scene.







HDS-720 Network AV controller can do the video tracking after connecting conference system or camera with internet or control cable.

HDS-720 Network AV controller machine required HDMI signal output to the monitor with HDMI input. It will show the camera's image.

Connecting HDS-720 to the monitor's HDMI input with HDMI cable, and switching the monitor to HDMI channel.

Remote Control_Log in



Open internet browser.





Enter the IP address to the adress.



Choose the language in the login page, English ,Chinese(Traditional), Korean are available.



Logging with account/password.

The network setting of HDS-720 can be DHCP or Static IP. To confirm the IP address, using HDMI output to check current IP address.

Logging into the webcontrol with the browser in the device. For example: Chrome ` Microsoft Edge or Firefox, etc. Entering the IP of HDS-720 to the address to connect to the web-control surface.

After log in to the control website, log in with the account and password. The preset account is "admin", preset password is "00000". Changing password





First time log into HDS-720's web control, system ask the user to set the conference system and camera first.

Click "Setting now" to go "Equipments" to set up the camera and conference unit.



Log in first time need to set the equipment first.

Equipments

≡ () HDS-720				🌐 ENGLISH 🗸 💄 ADMIN
Monitor Table				
Microphone Table	Camera			
🚱 Equipments				
Sustam			0	
			∕ ⊙ ∎	
	Monitor			
	FCS			
	IP 192.168.2.101 SCAN	SAVE		
BXB Electronics Co., Ltd.				



Equipments_Camera



Click" \times " to close the preview window.

2

Camera Iscan Centera 10 Status 1P SN Name Command 1 Online 192.168.2.110 VIPA.052233 Image: Command Image: Command 2 Online 192.168.2.111 VIPA.052233 Image: Command Image:	HDS-720				⊕ EN	IGLISH 🗸 🔔 ADMIN
Camera 10 Status IP SN Name Command 1 Online 192.168.2.110 V69.4.02233 Image: Command 2 Online 192.168.2.111 V69.4.02233 Image: Command Monitor Status IP SN Name Command FCS Image: SCAN Image: SCAN Image: SCAN Image: SCAN Image: SCAN	Camera					
1 Online 192.168.2.110 V89A052233 Image: Comparison of Comparison						
2 • Online 192.168.2.111 V/99.4.02233 • • • • • • • • • • • • • • • • • •						0
Monitor SCAN Monitor ID Status IP SN Name Command FCS IP 192.168.2.101 SCAN SAVE						
Monitor ID Status IP SN Name Command FCS IP 192.168.2.101 SCAN SAVE	Monitor					SCAN
FCS 19 192.168.2.101 SCAN SAVE						
IP 192.168.2.101 SCAN SAVE	FCS					
	IP 192.168.2	2.101	SCAN	SAVE		
Status Online	Status Online					

Click " • to preveiw each camera's image.



Setting each camera's ID and Name, also check the status of the camera.

To set the IP camera of HDS-720, use "SCAN" to check the online IP camera. Also set up the ID and the name of the camera for further use.

"Status" can check the IP camera communication status. "Online" means the IP camera working normally, you can control and receive the image from camera. "Offline" means HDS-720 can't receive the signal from IP camera, unable to control and preview the camera.



192.168.2

Equipments_FCS



Click "SCAN" to check the online conference system. (Only for FCS-6350)

HDS-720				en	GLISH 🗸 👱 ADMIN
Camera					
					o 📋
					◎
Monitor				\sim	
FCS					
IP <u>192.168</u>	.2.101	SCAN	SAVE		

Enter the IP of FCS-6350 manually is also possible. Click "SAVE" after set up.

2

≡ 🔘 HDS-720				🕀 ENGLI	SH 🗸 💄 ADMIN 🗧
Camer	ra				
Came					
1					•
:					▶ ∎
Monit					SCAN
Moni	192.168.2.101		0004a30000b2		
FCS				RETRY	
IP	192.168.2.101	SCAN	SAVE		
Status					

Select the FCS-6350 which need the camera tracking function.



Status shows the connection status of FCS-6350.

Connecting HDS-720 with FCS-6350 conference CCU makes camera tracking function available. Use " SCAN" to check the online FCS-6350, entering IP manually is also available.

"Status" can check the FCS-6350 communication status. "Online" means the FCS-6350 normally, you can do the camera tracking. "Offline" means HDS-720 can't receive the signal from FCS-6350, unable to do the camera tracking..

Check the IP address of FCS-6350 in the front panel. [Advance setting>IP adress]



Camera Tracking Setting

Camera ID Preset ID 🛈	
1 2 3 4 Home	
5 6 7 8 Zoom	
9 10 11 12	
Speed <u>o Auto</u> 13 14 15 16	
Remove Go To Set	



Camera Tracking Setting

ENGLISH V ADMIN Ammera SGAN Camera 10 Status 1P SN Name Command 1 · Online 192.168.2.110 V#6A02223 · • • • 2 · Online 192.168.2.111 V#8A02223 · • • • Monitor Status 1P SN Name Command FCS 1P 192.168.2.101 SGAN SAVE Status Online

Click the" ^(e) " image on the up-left of the page to switch to the camera controlling and preview page.

2



Choose the camera ID to control the camera and set the preset ID location.

Camera tracking setting page is able to preview and control each camera. Setting the location for each microphone makes the conference system able do the camera tracking. The microphone ID with the location setting will show in green like "001".

Controlling the camera by Up, Down, Left, Right, Zoom. Also choose the microphone ID to do the setting.



Click "Set" after setting the location for microphone.

Click "Go To" can check the previous setting location for specific microphone ID. "Remove" will delete the location setting for microphone.





Camera ID's color also able to check the status of each camera. White "2": It's online status. Able to control and set the camera. Green "2": It has the location setting of selected Preset ID. Red"2": It's offline, unable to control and set the camera tracking.

If the camera is installed up side down, the image is reversed. Use the remote control LIJ " " Mirror button to make the image upright.





≡ ⊙ HDS-720		🌐 ENGLISH 🗸 🔔 ADMII
Monitor Table		
Microphone Table Sequipments	Obtain IP Automatically	
🗘 System		
	IP 192.168.2.103	
	Gateway 192.168.2.1	
		SAVE
BXB Electronics Co., Ltd.		



System _ NETWORK

O h05-720 O h05-720 A same I same I

To set the DHCP function, check "Obtain IP Automatically"

2



Turn off "Obtain IP Automatically", need to set the static IP address manually.

HDS-720 network setting can choose whether DHCP or static IP address. Open "Obtain IP Automatically" to set the system as DHCP. For the DHCP system, open "Show IP on screen" to see current IP on starting image.

Close "Obtain IP Automatically" to make the system as static IP address. User is able to set up the network according to their needs. But "169.254.X.X" is not allowed to set as static IP.

HDS-720 default setting is DHCP, if DHCP is not able to have the IP address, it will set with default static IP address "192.168.168.120".

 ● H05-720
 ● FAGLER ▼ ▲ LANN
 □

 NETWORK
 0
 UPGATE
 PHESTE

 Description
 ●
 ●
 ●

 Bescription
 ●
 ●
 ●

 LAGC
 22 64 AR
 29
 ●

 LAGC
 22 55 353.0
 ●
 ●

 Catereay
 192 168 2.1
 ■
 ■

Turn on/off show IP on screen to enable/unable to see the IP in HDMI output.



IP Address will show on the lower-right of the starting image.



3



Connecting HDS-720 with UFO/EDC conference unit by RS-232 also able to do the camera tracking.

With the BXB UFO series, choose "UFO-2050". With BXB EDC series, choose "EDC-1051" to do the camera tracking.

X EDC series don't have the function of "HOME GO".





	MIN 🕀
NETWORK IO UPDATE ALL PRESETS	
Serial Number 0015	
Now version 1.0.0	
Check update Lastest version	
New version	

Connecting HDS-720 with internet to do the online update.

"Now version" shows the firmware version now, check the online clouds with internet to check if there's any update. If there is, online update is also available.



System _ ALL PRESETS



Click" "in each camera will delete all the setting of selected camera preset location.



Click " **I** to delete all the presets of all the camera.

2



After delete the preset location of each camera, camera won't track anymore.



ALL PRESETS allows you to check all the preset microphone of each camera in the system. To delete specific or all the camera's preset setting, clicking the icon to remove.

Once deleting the presets setting, the setting will be permanently removed from the system. To reset the location setting, go back to camera tracking setting page. (For the setting steps, please refer to P.11)

Go back to camera tracking setting page by clicking "⁽²⁾" to set the camera tracking again.



Appendix _ HDC-713 Camera Setting



Open the web control of IP camera, log in with account and password.

2



Go to "Setting">"Network" to setup the network, Check the RTSP>Enable Multicast.

Log in to the web control through browser like Chrome, Microsoft Edge ro Firefox. Enter the IP of HDC-713 to log into web remote control.

Default account/password of HDC-713 is admin/00000.

To check the IP address of HDC-713, connect HDMI output to monitor. Using remote control, Menu>Network>IP Address.

HDC-713	Video
the View	Contra E
Add / Edit Usive	Brean Mode Chat 4
G Settings	Calls (#354-60/ED) *
Carera Contra Co	Personal H264 TelePol/PERED +
Poles	timest times
Auto Concession	Fame Rate 10 + Sec
Network	Eil Flage 2007 Stops
A Mentenance	Rate Control VIII. •
(i) About	86 L
	38
	12

Go to "Setting">"Video"> "Advanced"



Set the IP Ratio to 10, check "Force Frame", click OK to save the setting.



3



BXB Electronics Co., Ltd.,

6F-1, No.288-5, Xinya Rd., Qianzhen Dist., Kaohsiung City 80673, Taiwan

TEL:+886-7-970-3838

FAX: +886-7-970-3883

E-mail: bxb@bxb.tw