

## Secure Mini-Matrix Switch



### Models:

SX42DU-3 – Secure 4-Port Mini-Matrix Switch

## TABLE OF CONTENTS

<b>Introduction .....</b>	<b>2</b>
HSL Secure Mini Matrix.....	2
 <b>Installation.....</b>	 <b>3</b>
Installing the Mini Matrix.....	3
 <b>Operation.....</b>	 <b>6</b>
Operating the Mini Matrix.....	6
Preset #1 (default) { L CTRL   L CTRL   F11   F1 }.....	9
Preset #2 { L CTRL   L CTRL   F11   F2 }.....	10
Preset #3 { L CTRL   L CTRL   F11   F3 }.....	11
Preset #3 { L CTRL   L CTRL   F11   F3 }.....	12
Preset #4 { L CTRL   L CTRL   F11   F4 }.....	13
Preset #4 { L CTRL   L CTRL   F11   F4 }.....	14
Preset #5 { L CTRL   L CTRL   F11   F5 }.....	15
Preset #6 { L CTRL   L CTRL   F11   F6 }.....	16
Keyboard shortcut options.....	17

## INTRODUCTION

### **HSL Secure Mini Matrix**

HSL's K224E is a secure 4 port Mini-Matrix KVMA switch which allows a single user to share two displays and a single set of keyboard, mouse & audio between multiple computers that belong to different security classifications levels while isolating all coupled hosts from each other keeping the data of each computer completely separate and protecting against data leakage and malicious attacks through shared USB, keyboard, mouse, video and audio peripherals.

This guide instructs how to install, configure and operate HSL's Mini Matrix.

## INSTALLATION

## Installing the Mini Matrix

## Step 1 – Cable Installation

## 1. Connect console port peripherals:


- Connect video displays to the Mini Matrix primary and secondary display ports.

**Note:** it is highly recommended to use identical primary and secondary display models. EDID information is taken from the primary console display port (#1) and sent to all connected computers. In case of using non-identical displays, connect the smaller display to the primary console display port.

- Connect keyboard, mouse and audio peripherals to the Mini Matrix console ports. These will be shared securely between all sources.
  - Connect a smartcard/biometric reader to the combiner's console fUSB secure port to support user authentication across multiple isolated sources.
2. Computer/Source channel ports:
- For each source, connect the video, keyboard, mouse, fUSB and audio cables to the Mini Matrix source ports.

## 3. Dual screen support:


- Download and install HSL's Multi Display Driver on source computers that have multiple screens (currently available only for Windows)( <http://highseclabs.com/dl.php?fid=446>).



## INSTALLATION

**Step 2 – Power ON the Mini Matrix**

- Turn ON all the PCs.
- Connect the power supply and power ON the Mini Matrix (approximate boot time is 10 seconds).
- The Mini Matrix boots into duplicate-mode, where source number 1 is presented on both displays.



**Note:** In case no picture is presented after powering ON, switch between the primary and secondary displays, or, connect an alternate display, or perform a reset to factory default.

## INSTALLATION

### Step 3 – Reset to Factory Defaults

Reset to factory defaults clears the device settings and restores the device to its original configuration.

- System reset, clears behavioral characteristics such as mouse settings and display presets. Type { **L CTRL** | **L CTRL** | **F11** | **r** } key combination.
- Complete reset: clears all device settings and resets to factory defaults. From the Terminal menu select the “Reset to Factory Defaults” option (refer to terminal mode guide).

#### Important Notes:

1. Always use the **left control key (CTRL)** unless otherwise specified.
2. Keyboard shortcut keys are to be pressed sequentially
3. Do not use the numeric keypad for toggling shortcuts unless otherwise specified.
4. ALL KEYBOARD SHORTCUTS REFER TO QWERTY KEYBOARDS. In case a non-qwerty keyboard is in use, keep using the QWERTY layout.



## OPERATION

## Operating the Mini Matrix


### Step 1 – Display & Control Options

Display & Control options define which source to display and control on each screen. Source selection is done through the source selection buttons on the front panel or via the DCU (dedicated control unit) port.



- Use the Source Selection Panels to choose which source to display on each screen.
- The left panel controls which source to display on the Primary display while the right panel controls the secondary display.
- For example, as seen in the illustration, when #1 is selected on the Primary Panel and #3 is selected on the Secondary panel, the selected sources will be presented accordingly.
- A source can be duplicated, by selecting its number on both panels.
- By default, Mouse, Keyboard, Audio and fUSB peripherals follow the display association.

- Freeze Audio and fUSB option buttons allow the operator to switch peripheral and audio ports independently of the source being displayed.
- Additional options are described ahead under the advanced presets section.



## OPERATION

## Step 2 – Relative vs Absolute Mouse

By default the Mini Matrix is setup with relative mouse settings.


- **Relative mouse** (default) confines the mouse movement to the screen of each selected computer. To switch the mouse between sources, use the front panel push buttons.
- **Absolute mouse** (VDT) allows switching the mouse between sources by moving the mouse cursor across display borders.

### Cursor Navigation (Virtual Display Technology - VDT):

- With cursor navigation the user can move from one highly isolated computer system to another by simply moving the mouse cursor across display borders.
- Once the cursor crosses the display border, Keyboard, Mouse, Audio and USB mapping switch to the computer that is connected to that display.
- No need to push any buttons.

### How to define mouse state

- Use the key combination { **L CTRL | L CTRL | F11 | c** } to enable absolute mouse (VDT).
- Use the key combination { **L CTRL | L CTRL | F11 | b** } to enable relative (this is the default mode).





## OPERATION

### Step 3 – Predefined Display Layouts (Presets)

#### What are presets?

- Presets reflect the layout and borders of computer displays to the Mini Matrix.
- The Mini Matrix includes 6 predefined presets, described below.

#### What are presets for?

- Presets allow the Mini Matrix to correctly associate the mouse with each source based on the physical display positioning and the respective number of displays which are associated with each source.
- Presets enable cursor navigation switching which allows the user to switch control between PCs by moving the mouse cursor across display borders.

#### How to switch between presets

- Use the key combination { **L CTRL | L CTRL | F11 | F1-to-F6** } to toggle between presets.

**Enable absolute-mouse prior to working with presets, type:**  
{ **L CTRL | L CTRL | F11 | c** }.


## OPERATION

**Preset #1 (default) { L CTRL | L CTRL | F11 | F1 }**

- 2 display-monitors (monitor 1 & 2) are connected to the Primary and Secondary console ports.
- 4 single-display sources (PC 1-4) are connected to the Mini Matrix source ports 1-4.
- Display-monitors are aligned horizontally so that the Primary screen is on the left and the Secondary is on the right.
- VDT mouse cursor movement axis is horizontal.

**Highlights:**

- Use the source selection panel to choose which sources to display.
- Switch between selected sources by dragging the mouse cursor horizontally.




## OPERATION

**Preset #2 { L CTRL | L CTRL | F11 | F2 }**

- 2 display-monitors (monitor 1 & 2) are connected to the Primary and Secondary console ports.
- 4 single-display sources (PC 1-4) are connected to the Mini Matrix source ports 1-4.
- Display-monitors are aligned vertically so that the Secondary screen is on top of the Primary screen.
- VDT mouse cursor movement axis is vertical.

**Highlights:**

- Use the source selection panel to choose which sources to display.
- Switch between selected sources by dragging the mouse cursor vertically.



## OPERATION


**Preset #3 { L CTRL | L CTRL | F11 | F3 }**

- 2 display-monitors (monitor 1 & 2) are connected to the Primary and Secondary console ports.
- 1 display-monitor (monitor 3) is connected directly to PC #1 primary-display adapter.
- PC #1 secondary-display adapter is connected to the Mini Matrix source port 1.
- 3 single-display sources (PC 2, 3, 4) are connected to the Mini Matrix source ports 2, 3, 4.
- All display-monitors are aligned horizontally so that the Primary screen of PC#1 is on the left, the Mini Matrix Primary screen is in the middle and the Mini Matrix Secondary screen is on the right.
- VDT mouse cursor movement axis is horizontal.

Download and install HSL's Multi Display Driver on source computers that have multiple screens (currently available only for Windows).

**Example #1**


VDT cursor navigation applies to Monitor 3 even though it is connected directly to PC#1



## OPERATION

**Preset #3 { L CTRL | L CTRL | F11 | F3 }****Example #2**

Monitor 3 constantly displays PC#1 Primary screen even when switching to other sources



## OPERATION

**Preset #4 { L CTRL | L CTRL | F11 | F4 }**


Same as Preset #3 while source #4 is directly connected to a primary screen.

- 2 display-monitors (monitor 1 & 2) are connected to the Primary and Secondary console ports.
- 1 display-monitor (monitor 4) is connected directly to PC #4 primary-display adapter.
- PC #4 secondary-display is connected to the Mini Matrix source port 4.
- 3 single-display sources (PC 1, 2, 3) are connected to the Mini Matrix source ports 1, 2, 3.
- All display-monitors are aligned horizontally so that the Mini Matrix Primary screen is on the left, the Mini Matrix Secondary screen is in the middle and the Primary screen of PC#4 is on the right.
- VDT mouse cursor movement axis is horizontal.

Download and install HSL's Multi Display Driver on source computers that have multiple screens (currently available only for Windows).

**Example #1**


VDT cursor navigation applies to Monitor 4 even though it is connected directly to PC#4



## OPERATION

**Preset #4 { L CTRL | L CTRL | F11 | F4 }****Example #2**

Monitor 4 constantly displays PC#4 Primary screen even when switching to other sources




## OPERATION

**Preset #5 { L CTRL | L CTRL | F11 | F5 }**

Combines Preset #3 and Preset #4.

- 2 display-monitors (monitor 1 & 2) are connected to the Primary and Secondary console ports.
- 2 display-monitors (monitor 3 & 4) are connected directly as primary-displays to PCs #1 and #4 respectively.
- PCs #1 and #4 secondary-display adapters are connected to the Mini Matrix source ports 1 and 4.
- 2 single-display sources (PC 2, 3) are connected to the Mini Matrix source ports 2, 3.
- All display-monitors are aligned horizontally so that the Primary screen of PC#1 is on the left and the Primary screen on PC#4 is on the right. The Mini Matrix Primary and Secondary screens are in the middle.
- VDT mouse cursor movement axis is horizontal.



Download and install HSL's Multi Display Driver on source computers that have multiple screens (currently available only for Windows).

**Highlights:**

- Display and control PC#1 & PC#4 dual-displays.
- Control PC#2 and PC#3 while displaying the primary screens of PCs 1 and 4.



## OPERATION

**Preset #6 { L CTRL | L CTRL | F11 | F6 }**

- 2 display-monitors (monitor 1 & 2) are connected to the Primary and Secondary console ports.
- 2 dual-display sources (PC 1 & 2) are connected to the Mini Matrix source ports 1-4.
- Display-monitors are aligned vertically so that the Secondary screen is on top of the Primary screen.
- VDT mouse cursor movement axis is vertical.


**Highlights:**

Use the source selection panel to choose which sources to display.

View and control any monitor combination, such as:

- PC#1 Primary and Secondary screens.
- PC#2 Primary and Secondary screens.
- PC#1 and #2 Primary screens
- PC#1 and #2 Secondary screens
- PC#1 Primary and PC#2 Secondary.
- PC#2 Primary and PC#1 Secondary.

Switch between selected sources by dragging the mouse cursor vertically.



Download and install HSL's Multi Display Driver on source computers that have multiple screens (currently available only for Windows).

## OPERATION

## Keyboard shortcut options

#	Action Description	Keyboard
1	Toggle between mouse modes	(Absolute) - <b>L CTRL   L CTRL   F11   c</b> (Relative) - <b>L CTRL   L CTRL   F11   b</b>
2	Freeze mouse on active channel	(Freeze) - <b>L CTRL   L CTRL   F11   f</b> (Un Freeze) - <b>L CTRL   L CTRL   F11   u</b>
3	Increase / Decrease mouse speed	(Increase) - <b>L CTRL   L CTRL   F11   +</b> (Decrease) - <b>L CTRL   L CTRL   F11   -</b>
4	Change presets	<b>L CTRL   L CTRL   F11   F1 – F6</b>
5	System Reset to factory defaults	<b>L CTRL   L CTRL   F11   r</b>
6	Enter Terminal-Mode	<b>L CTRL   R CTRL   t</b>





# Highseclabs.com

©2016 All rights reserved. HSL logo and product names are trademarks or service trademarks of HighSecLabs Ltd (HSL). All other marks are the property of their respective owners. Images for demonstration purposes only. This document may contain confidential and/or proprietary information of HSL Corporation, and its receipt or possession does not convey any right to reproduce, disclose its contents, or to manufacture or sell anything that it may describe. Reproduction, disclosure, or use without specific authorization from HSL Corporation is strictly prohibited.