# KRAMER





## KT-107SC / KT-107SCRB Quick Start Guide

This guide helps you install and use your KT-107SC / KT-107SCRB for the first time.

Go to www.kramerav.com/downloads/KT-107SC to download the latest user manual and check if firmware upgrades are available.

### Step 1: Check what's in the box

- or KT-107SCRB KronoMeet Touch Panel (Reduced Bandwidth)
- ✓ 1 C-USB/Micro B cable
- ☑ Installation screws ☑ Panel mount plate

✓ 1 right-angle OTG USB cable

(13)


(11)

厕

(12)

04

## Step 2: Get to know your KT-107SC / KT-107SCRB



#	Feature	Function
1	Hidden Reset Button	Located on top side. Insert a pin and hold for a few seconds to reset <b>KT-107SC</b> .
2	Light Sensor	Automatically adjusts the screen brightness according to the room lighting conditions.
3	Activity RGB LED	Lights green when powered, flashes green when charging the battery, lights red when camera is on.
4	Camera	For remote room viewing or video conferencing.
5	Microphone	For audio communication, recording or conferencing.
6	Speakers	To output the sound.
7	Tabletop Mount Connector	For connecting to the tabletop mount.
8	Cover	Covers the wall mount connections and power button.
9	Power Button	Press to power on the <b>KT-107SC</b> . When powered, press briefly to open the pop-up menu and power down the device, reboot it or return to the Home-page. Press and hold to power down the device immediately. This button is also used for firmware upgrade.
10	Volume-up Button	Used for firmware upgrade. Use also to increase KT-107SC speaker volume.
11	Micro USB Port	For connecting to an adjacent on-wall USB device and for firmware upgrade.
12	Flat Cable Connector	For connecting to the on-wall mount unit.
13	Connecting Holes	For connecting to the panel mount plate. To prevent potential damage to the KronoMeet Touch Panel, use only Kramer supplied screws and mounts.





Rev:

P/N: 2900-301337QS


### Step 3: Mounting the KT-107SC / KT-107SCRB

#### Mounting on the wall:

Before mounting KT-107SC on a wall, install an in-wall junction box (recommended boxes are listed in the user manual)

- Attach the on-wall mount unit to the installed junction box (top side up see indication arrows on unit). Connect Ethernet and/or power cables and optionally, insert the right-angle USB cable (supplied) for connecting to an adjacent external USB device.
- 2. Screw the 4 wall-mounting screws (supplied) through the screw openings. The various screw openings fit various types of wall junction boxes.
- 3. On the rear side of the **KT-107SC**, remove the screw cover and the cover (by slightly pressing downwards and then pulling out) and set aside.
- 4. Attach the panel mount plate to the rear side of the **KT-107SC** (using 4 M2x4 screws, supplied).
- 5. Connect the flat cable from the on-wall mount (attached to the inwall junction box) to the connector on the rear of **KT-107SC**.
- 6. Hang the **KT-107SC** on the wall by sliding the tabs on the attached panel mount plate over the grooves on the on-wall mount unit.

For optimum range and performance use the recommended Kramer cables available at <u>www.kramerav.com/product/KT-107SC</u>. Using third-party cables may cause damage!





Caution:

- Ensure that the environment (e.g., maximum ambient temperature & air flow) is compatible for the device.
- Avoid uneven mechanical loading.
- Appropriate consideration of equipment nameplate ratings should be used for avoiding overloading of the circuits.
- Reliable earthing of rack-mounted equipment should be maintained.
- Maximum mounting height for the device is 2 meters.

#### Step 4: Connect the power

Connect the power cord to KT-107SC and plug it into the mains electricity.



• There are no operator serviceable parts inside the unit. Warning:

- Use only the power cord that is supplied with the unit.
- Disconnect the power and unplug the unit from the wall before installing.

Safety Instructions (See www.kramerav.com for updated safety information)

### Step 5: Customizing the KT-107SC / KT-107SCRB settings

The Settings page is accessible from the Home-page and enables customizing the KT-107SC settings:



<b>∼</b>	Settings							∎ 10.46 Q
0	Control			÷	Users			
•	ScreenshotSetting							
Personal								
•	Location			â	Security			
	Accounts			G	Google			
۲	Language & input			٥	Backup & reset			
Syst	em							
0	Date & time			÷	Printing			
0	About touch panel							
	ō.	Ø	$\bigtriangledown$	0				

To operate KT-107SC for the first time:

- 1. Turn the power on the rear of the touch panel to ON. Wait for Kramer KronoMeet log-in page to load.
- 2. Press **power button** (9) on the rear of the panel to exit the KronoMeet app.
- 3. Enter the default password (Kramer) and proceed to the Home Screen.
- 4. Make sure thew device is connected to the Internet.
  - If the device is connected to the Internet via Wi-Fi:
    - Press the power button (on the KT-107SC rear panel) and enter the default password (Kramer).
    - Click Home Page>Settings>Wi-Fi and choose your SSID Network.
    - Reboot your device.
- Check the Google Play Store to ensure that KT-107SC is running the latest version of KronoMeet App.

To Launch the KronoMeet App and activate the KronoMeet panel:

- 1. Enter your KronoMeet Activation Code for this meeting space from the KronoMeet dashboard
- 2. Click Activate on the panel.

Write is inclusive

 • Writi

 • Writi

 • More

 • More

 • Distary

 • Distary

 • More

 • Distary

 • More

 • Distary

 • Distary
</

To r	nodifv	date	and	time	settings:
------	--------	------	-----	------	-----------

- 1. In the Home-page, click Settings.
- 2. Scroll down to the System area and click Date & time.
- 3. Enable **Automatic date & time** to derive the date and time from the Network. When disabled, enter the date and time manually.
- 4. Select the time format.

▲ 🖬 🖷					▼ 📕 1:36
← Date & time					
Automatic date & time Use network-provided time					•
Automatic time zone Use network-provided time zone					•
Set date January 30, 2017					
Set time 1:36 PM					
Select time zone GMT+02:00 Eastern European Standa					
Use 24-hour format 1:00 PM					
Ċ'	٩	$\triangleleft$	0	٩	

To modify display settings:

- 1. In the Home-page, click Settings.
- 2. Select Display.
- 3. Set the following (as required):
  - Brightness: brightness level, adaptive brightness
  - Status Bar: Show/hide lower and/or top status bar
  - Auto Sleep: Sleep timeout.

A 0		7:49
÷	Display	
Brigi	itness level	
Adaj Optir	ntve brightness level for available light	۲
Wall	paper	
Slee		
Font		
	n device is rotated at the contents of the screen	
Cast		
Cont	ent Adaptive Brightness Control	
Alwa	ys hide the status bottom bar	

#### For KT-107SC model: FCC-ID-R8S-KT-107

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation of the device is subject to the following conditions:

- This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation

Recommendations for safe exposure to non-ionizing radiation: Only use the device at least 20 centimeters away from your body.

