KRAMER





Scan for full manual

WP-871xr/WP-789T EU PANEL SET Quick Start Guide

This guide helps you install and use your WP-871xr/WP-789T EU PANEL SET for the first time.

Step 1: Check what's in the box

1 faceplate

1 UK frame


1 EU frame

1 Quick start guide

Step 2: Install the WP-871xr/WP-789T EU PANEL SET

After mounting the device (see www.kramerav.com/downloads/WP-871xr/WP-789T EU PANEL SET) attach the frame to the device and then click in the faceplate as shown in the illustration below:

European Version



We recommend that you use any of the following standard 1 Gang in-wall junction boxes (or their equivalent):

- EU: 1 Gang in-wall junction box, with a cut-hole diameter of 68mm and depth that can fit in both the device and the connected cables (DIN 49073).
- **UK**: 1 Gang in-wall junction box, 75x75mm (W, H), and depth that can fit in both the device and the connected cables (BS 4662).

WP-871xr/WP-789T EU PANEL SET Quick Start (P/N: 2900-301047QS REV 1)

Rev: