


Use a USB cable to connect the USB-type C interface of the speakerphone to the USB interface of the PC. Set the speakerphone as the default audio device of the PC. Figure 4-2 shows the connection method.


## Conference Speakerphone




## OTA Software Update for Connected Devices

4-stage cascading. The master cascading device  
er adapter and the USB cable. One end of the  
-type C interface of the microphone and the  
interface of the Video Conference Terminal/PC/  
ding device is connected using the network cable.  
method.

1、Download the software and connect the device  
Official website address: <https://www.hitrolink.com/?show=66>





2、Click on the package. Click



platform will push the firmware upgrade

### 3、Upgrade completed






## Conference Speakerphone


V1.0.0

1.2.51.32.24951-000

## Button Instructions



## Port Descriptions



Green indicator light: Device powered on

Interface No.	Name	Meaning
1	Power supply interface	Connects the power adapter for power supply to the device
2	Network interface PREVIOUS	Cascades the previous device
3	Type C interface	Performs data transfer and power supply through USB-type C
4	Network interface NEXT	Cascades the next device

### Notes

The power adapter and Type C interface connect only the first device.

## Connecting a single device

Use a USB cable to connect the USB-type C interface of the microphone to the USB or H-bridge interface of the conference terminal. The microphone can be set as an audio device of the conference terminal. Figure 4-1 shows the connection method.

### Conference Speakerphone

